



## WATCH SETTING

TWO-position crown

1. Neutral and winding position

Allows the user to manually wind their watch by turning the crown upwards.

2. Time setting position

Allows the user to set the time by turning the crown and setting the hands to the right time.



## CAUTION

Every time you change the time, remember to put the crown back in position 1.

## WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.